



TE460-137 Firmware Upgrade

The firmware update requires a Windows PC with a copy of the new firmware and a USB cable, Type A to Micro, male-male. This cable is included with the TE460-137.


1. Connect the USB cable between the computer and the TE460-137 and turn on the TE460-137.
2. Use the MENU button to select the Main Menu and then use the UP/DN arrows to select the **Setup** option.



3. Press the ENTER key to enter the setup page.
4. Use the UP/DN arrows to select the **Firmware Upd** option.
5. Press ENTER to highlight the Yes or No option. When **Yes** is visible, press ENTER to enter update mode.




In update mode, the following screen is displayed and a window opens on the computer.




Warning: Do NOT turn off power to the TE460-137 during the remaining steps.

6. Copy the file from the computer to the new window that just opened; named USB UPDATE.



After a few seconds, the file copy is complete.



7. At this time, the TE460-137 automatically reboots with the new firmware.

The initialization now displays v1.14A. The update is complete.